

# GRYPHON

# Brass Fittings Catalogue



Cost-effective fittings line

phon

- Robust with reliable performance
- Qualified with GryphonFlex tube

### INDEX A

### INDEX B →

	B1101 Ball Valve				B1102 Forged 90° Elbow	B1103 Coupling
BRASS BALL VALVE			BRASS PIPE FITTINGS	s		
		41	PHAN		B1	B1
B1104 Cap	B1105 Reducer Bushing	,	B1107 Close Nipple		B1107 Long Nipple	B1108 Plug Socket
Сир	Nedocer Boshing	9	Close Mipple		Long Hippic	1 log socket
<b>B</b> 1		B2	₽ B	2	B2	B3
B1109	B1110		B1111		B1113	B1114
Straight	Plug		Hex Nipple		Extruded 90° Elbow	Extruded Tee
B3		33	В	4	B4	B4
B1115	B1116		B1117		B1118	
Extruded Branch Tee	Extruded Run Tee		Extruded 90° Elbov	,	Extruded 45° Elbow	
B5		35	B:	5	B5	
BRASS HOSE FITTINGS	Straight		B3702 Hose Splicer			Just Click to go to the page
	(	C1	C	:1		the page
BRASS PUSH-LOK	B3801 PUSH-LOK Straight		B3802 PUSH-LOK Straight 45° Swivel	ı	B3803 PUSH-LOK Straight 37° Swivel	
HOSE FITTINGS		<b>D</b> 1	<b>#</b>	1	<b>==</b>	
BRASS PUSH-TO-CONNECT D.O.T.	B4001 Straight Air Brake Union	1	B4002 Air Brake Union Tee		B4003 Air Brake 90° Elbow	B4004 Straight Air Brake Union
AIR BRAKE FITTINGS for D.O.T. Air Brake Tube	SE SE	1		<b>:</b> 1	<b>E1</b>	E1

### ←INDEX A

### **INDEX B**

	B4005	B4006	B4007	B4008
BRASS PUSH-TO-CONNECT	Air Brake Straight	Air Brake 90° Elbow	Air Brake 90° Elbow, Swivel	Air Brake Run Tee
D.O.T. AIR BRAKE FITTINGS for D.O.T. Air Brake Tube	E2	F2	E3	E3
B4009 Air Brake Run Tee, Swivel	B4010 Air Brake Branch Tee	B4011 Air Brake Branch Tee, Swivel	B4012 Air Brake 45° Elbow	B4013 Air Brake 45° Elbow, Swivel
E3	E3	<b>E4</b>	E4	E4
BRASS COMPRESSION D.O.T.	Air Brake Compression D.O.T. Sleeve	B4202 Air Brake Compression D.O.T. Nut	B4203 Air Brake Compression D.O.T. Straight	B4204 Air Brake Compression D.O.T. Tee
AIR BRAKE FITTINGS with fixed inserts	F1	F1	F1	F1
B4205 Air Brake Compression D.O.T. Straight	Air Brake Compression D.O.T. 90° Elbow	B4207 Air Brake Compression D.O.T. Run Tee	B4208 Air Brake Compression D.O.T. Branch Tee	Air Brake Compression D.O.T. 45° Elbow
F2	F2	F3	F3	F3
BRASS D.O.T. AIR BRAKE HOSE	B4601 Air Brake D.O.T. Hose Coupling Sleeve	B4602 Air Brake D.O.T. Hose Coupling Nut_	B4603 Air Brake D.O.T. Hose Coupling Straight	B4605 Air Brake D.O.T. Hose Coupling Straight, Spring
COUPLINGS AND TERMINAL BOLTS	<b>©</b> G1	G1	G1	G1
B4606 Air Brake D.O.T. Hose Coupling Straight, MHAB	B4607 Air Brake D.O.T. Hose Coupling Straight, FHABX	B4608 Air Brake D.O.T. Hose Coupling Straight, MPX		— NAVIGATION —  Just  Click
G2	G2	G2		to go to the page
B1112 Terminal Bolt				
G2				







### **Brass Ball Valve**



<b>B1101</b> Bras	ss, Ball Valve		(	N.
	PART NO	FP	FP	ر کی کی
	B1101-04-04	1/4	1/4	
	B1101-06-06	3/8	3/8	
	B1101-08-08	1/2	1/2	
	B1101-12-12	3/4	3/4	
	B1101-16-16	1	1	
	B1101-20-20	1 1/4	1 1/4	
	B1101-24-24	1 1/2	1 1/2	
	B1101-32-32	2	2	



B1102 Adapt	or, Brass, NPT, 9	0° Elbow	
	PART NO	MP	MP
	B1102-02-02	1/8	1/8
	B1102-04-02	1/4	1/8
	B1102-04-04	1/4	1/4
	B1102-06-04	3/8	1/4
	B1102-06-06	3/8	3/8
	B1102-08-06	1/2	3/8
	B1102-08-08	1/2	1/2

B1103 Adaptor, Brass, NPT, Straight				
	PART NO	FP	FP	ر تعرب
	B1103-02-02	1/8	1/8	
	B1103-04-02	1/4	1/8	
	B1103-04-04	1/4	1/4	
	B1103-06-02	3/8	1/8	
	B1103-06-04	3/8	1/4	
	B1103-06-06	3/8	3/8	
	B1103-08-02	1/2	1/8	
	B1103-08-04	1/2	1/4	
45	B1103-08-06	1/2	3/8	
	B1103-08-08	1/2	1/2	
	B1103-12-06	3/4	3/8	
	B1103-12-08	3/4	1/2	
<b>F F</b>	B1103-12-12	3/4	3/4	

B1104	Adaptor, Brass, NPT, (	Cap	ale
	PART NO	FP	C.C.
	B1104-02	1/8	
	B1104-04	1/4	
	B1104-06	3/8	
	B1104-08	1/2	/
	B1104-12	3/4	



# B1105 Adaptor, Brass, NPT, Reducer Bushing



PART NO	MP	FP	ر تعجر
B1105-04-02	1/4	1/8	
B1105-06-02	3/8	1/8	
B1105-06-04	3/8	1/4	
B1105-08-02	1/2	1/8	
B1105-08-04	1/2	1/4	
B1105-08-06	1/2	3/8	
B1105-12-02	3/4	1/8	
B1105-12-04	3/4	1/4	
B1105-12-06	3/4	3/8	
B1105-12-08	3/4	1/2	
B1105-16-04	1	1/4	
B1105-16-06	1	3/8	
B1105-16-08	1	1/2	
B1105-16-12	1	3/4	



PART NO	MP	MP
B1107-02-02	1/8	1/8
B1107-04-04	1/4	1/4
B1107-06-06	3/8	3/8
B1107-08-08	1/2	1/2

# B1107 Adaptor, Brass, NPT, Nipple, Long



PART NO	MP	MP	ا ر څور	
B1107-02-02-X2.0	1/8	1/8	2.00	
B1107-02-02-X3.0	1/8	1/8	3.00	
B1107-04-04-X2.0	1/4	1/4	2.00	4
B1107-04-04-X3.0	1/4	1/4	3.00	
B1107-06-06-X2.0	3/8	3/8	2.00	
B1107-06-06-X3.0	3/8	3/8	3.00	
B1107-08-08-X2.0	1/2	1/2	2.00	
B1107-08-08-X3.0	1/2	1/2	3.00	
	Custom Length	s Available		



B1108 Adap			
	PART NO	MP	25 6 m
	B1108-01	1/16	
	B1108-02	1/8	
	B1108-04	1/4	
	B1108-06	3/8	
	B1108-08	1/2	
	B1108-12	3/4	
	B1108-16	1	

B1109 Adap	tor, Brass, NPT,	Straight		a le
	PART NO	FP	MP	25
	B1109-02-02	1/8	1/8	
	B1109-04-02	1/4	1/8	
	B1109-04-04	1/4	1/4	
	B1109-06-02	3/8	1/8	
	B1109-06-04	3/8	1/4	
	B1109-06-06	3/8	3/8	
	B1109-08-04	1/2	1/4	
	B1109-08-06	1/2	3/8	
	B1109-08-08	1/2	1/2	
1	B1109-12-06	3/4	3/8	
	B1109-12-08	3/4	1/2	
6.6	B1109-12-12	3/4	3/4	
77-1-5				

B1110 Adap	tor, Brass, NPT, I	Plug	
	PART NO	MP	J. 25.
	B1110-02	1/8	_
	B1110-04	1/4	
	B1110-06	3/8	
	B1110-08	1/2	
	B1110-12	3/4	
	B1110-16	1	
		1	



B1111 Adapto	or, Brass, NP	Г, Hex Nipple		DE.
	PART NO	MP	MP	ي تجور
	B1111-02-02	1/8	1/8	
	B1111-04-02	1/4	1/8	
Minne	B1111-04-04	1/4	1/4	
	B1111-06-02	3/8	1/8	
	B1111-06-04	3/8	1/4	
	B1111-06-06	3/8	3/8	
	B1111-08-04	1/2	1/4	
	B1111-08-06	1/2	3/8	
	B1111-08-08	1/2	1/2	
	B1111-12-08	3/4	1/2	
11.11	B1111-12-12	3/4	3/4	-
	B1111-16-16	1	1	
				**

B1113 Adaptor, Brass, NPT, 90 Elbow, Extruded				
	PART NO	FP	FP	
	B1113-02-02	1/8	1/8	
	B1113-04-04	1/4	1/4	
	B1113-06-06	3/8	3/8	
	B1113-08-08	1/2	1/2	
	B1113-12-12	3/4	3/4	

<b>B1114</b> Adaptor, Brass, NPT, Tee, Extruded				
	PART NO	FP	FP	FP
	B1114-02-02-02	1/8	1/8	1/8
	B1114-04-04-04	1/4	1/4	1/4
	B1114-06-06-06	3/8	3/8	3/8
	B1114-08-08-08	1/2	1/2	1/2
	B1114-12-12-12	3/4	3/4	3/4



# **B1115** Adaptor, Brass, NPT, Branch Tee, Extruded



PART NO	FP	FP	MP
B1115-02-02-02	1/8	1/8	1/8
B1115-04-04-04	1/4	1/4	1/4
B1115-06-06-06	3/8	3/8	3/8
B1115-08-08-08	1/2	1/2	1/2
B1115-12-12-12	3/4	3/4	3/4

B1116	Adaptor, Brass, NP7	r, Run Tee,	Extruded
	DADT NO	ED	MD



PART NO	FP	MP	FP
B1116-02-02-02	1/8	1/8	1/8
B1116-04-04-04	1/4	1/4	1/4
B1116-06-06-06	3/8	3/8	3/8
B1116-08-08-08	1/2	1/2	1/2
B1116-12-12-12	3/4	3/4	3/4

# **B1117** Adaptor, Brass, NPT, 90° Elbow, Extruded



PART NO	FP	MP	ر کیچر
B1117-02-02	1/8	1/8	
B1117-04-02	1/4	1/8	
B1117-04-04	1/4	1/4	
B1117-06-06	3/8	3/8	
B1117-06-06	3/8	3/8	
B1117-08-08	1/2	1/2	
B1117-12-12	3/4	3/4	

# **B1118** Adaptor, Brass, NPT, 45° Elbow, Extruded



PART NO	FP	MD
PARTINO	ГР	MP
B1118-02-02	1/8	1/8
B1118-04-04	1/4	1/4
B1118-06-06	3/8	3/8
B1118-08-08	1/2	1/2
B1118-12-12	3/4	3/4

### **Brass Hose Fittings**



# B3701 Adaptor, Brass, Barb, Straight



PART NO	HOSE I.D.	MP	25°
B3701-02-02	1/8	1/8	
B3701-02-04	1/8	1/4	
B3701-04-02	1/4	1/8	
B3701-04-04	1/4	1/4	
B3701-04-06	1/4	3/8	
B3701-04-08	1/4	1/2	
B3701-05-02	5/16	1/8	
B3701-05-04	5/16	1/4	
B3701-06-02	3/8	1/8	4
B3701-06-04	3/8	1/4	
B3701-06-06	3/8	3/8	~\\
B3701-06-08	3/8	1/2	
B3701-06-12	3/8	3/4	
B3701-08-04	1/2	1/4	
B3701-08-06	1/2	3/8	W
B3701-08-08	1/2	1/2	
B3701-08-12	1/2	3/4	
B3701-10-06	5/8	3/8	
B3701-10-08	5/8	1/2	
B3701-10-12	5/8	3/4	
B3701-12-08	3/4	1/2	
B3701-12-12	3/4	3/4	
B3701-16-12	1	3/4	
B3701-16-16	1	1	

# B3702 Adaptor, Brass, Barb, Straight, Hose Splicer



PART NO	HOSE I.D.	HOSE I.D.
B3702-02-02	1/8	1/8
B3702-04-04	1/4	1/4
B3702-05-05	5/16	5/16
B3702-06-06	3/8	3/8
B3702-08-08	1/2	1/2
B3702-10-10	5/8	5/8
B3702-12-12	3/4	3/4
B3702-16-16	1	1



### **Brass PUSH-LOK Hose Fittings**



# **B3801** Adaptor, Brass, PUSH-LOK, Straight



PART NO	HOSE I.D.	MP	755
B3801-04-02	1/4	1/8	
B3801-04-04	1/4	1/4	
B3801-04-06	1/4	3/8	
B3801-06-02	3/8	1/8	
B3801-06-04	3/8	1/4	
B3801-06-06	3/8	3/8	
B3801-06-08	3/8	1/2	
B3801-08-04	1/2	1/4	
B3801-08-06	1/2	3/8	
B3801-08-08	1/2	1/2	
B3801-08-12	1/2	3/4	
B3801-10-06	5/8	3/8	
B3801-10-08	5/8	1/2	
B3801-10-12	5/8	3/4	
B3801-12-08	3/4	1/2	
B3801-12-12	3/4	3/4	

## B3802 Adaptor, Brass, PUSH-LOK, Straight, Female, SAE 45° Swivel



PART NO	HOSE I.D.	FSAE	
B3802-04-04	1/4	1/4	
B3802-04-06	1/4	3/8	1
B3802-05-06	5/16	3/8	
B3802-06-06	3/8	3/8	
B3802-06-08	3/8	1/2	7
B3802-08-06	1/2	3/8	
B3802-08-08	1/2	1/2	
B3802-12-12	3/4	3/4	

# B3803 Adaptor, Brass, PUSH-LOK, Straight, Female JIC 37° Swivel



PART NO	HOSE I.D.	FJX
B3803-04-04	1/4	1/4
B3803-06-06	3/8	3/8
B3803-08-08	1/2	1/2
B3803-10-10	5/8	5/8
B3803-12-12	3/4	3/4

#### Push-to-connect, D.O.T. Air Brake Fittings



#### For D.O.T. Air Brake Tube

# B4001 Adaptor, Brass, PTC, D.O.T., Straight



PART NO	TUBE	TUBE
B4001-2.5-2.5	5/32	5/32
B4001-04-04	1/4	1/4
B4001-06-06	3/8	3/8
B4001-08-08	1/2	1/2
B4001-10-10	5/8	5/8
B4001-12-12	3/4	3/4

### B4002 Adaptor, Brass, PTC, D.O.T., Tee



PART NO	TUBE	TUBE	TUBE
B4002-04-04-04	1/4	1/4	1/4
B4002-06-04-06	3/8	1/4	3/8
B4002-06-06-06	3/8	3/8	3/8
B4002-08-08-08	1/2	1/2	1/2
B4002-10-10-10	5/8	5/8	5/8
B4002-12-12-12	3/4	3/4	3/4

# B4003 Adaptor, Brass, PTC, D.O.T., 90° Elbow



PART NO	TUBE	TUBE
B4003-04-04	1/4	1/4
B4003-06-06	3/8	3/8
B4003-08-08	1/2	1/2

# B4004 Adaptor, Brass, PTC, D.O.T., Straight



PART NO	TUBE	FP
B4004-04-02	1/4	1/8
B4004-04-04	1/4	1/4
B4004-06-04	3/8	1/4
B4004-06-06	3/8	3/8
B4004-08-06	1/2	3/8
B4004-08-08	1/2	1/2

### Push-to-connect, D.O.T. Air Brake Fittings



#### For D.O.T. Air Brake Tube

B4005 Ada	ptor, Brass, PT0	C, D.O.T., Straight		a le
	PART NO	TUBE	MP	م کھٹے۔
	B4005-02.5-02	5/32	1/8	
	B4005-04-02	1/4	1/8	
	B4005-04-04	1/4	1/4	
	B4005-04-06	1/4	3/8	
	B4005-06-02	3/8	1/8	
	B4005-06-04	3/8	1/4	
	B4005-06-06	3/8	3/8	
	B4005-06-08	3/8	1/2	
	B4005-08-04	1/2	1/4	-
	B4005-08-06	1/2	3/8	
17.00	B4005-08-08	1/2	1/2	
	B4005-10-06	5/8	3/8	
	B4005-10-08	5/8	1/2	
	B4005-12-08	3/4	1/2	
	B4005-12-12	3/4	3/4	

B4006 Adap	otor, Brass, PT	C, D.O.T., 90° Elbow		
	PART NO	TUBE	MP	
	B4006-04-02	1/4	1/8	
	B4006-04-04	1/4	1/4	
	B4006-04-06	1/4	3/8	
	B4006-06-02	3/8	1/8	
	B4006-06-04	3/8	1/4	
	B4006-06-06	3/8	3/8	
	B4006-06-08	3/8	1/2	
S	B4006-08-04	1/2	1/4	
	B4006-08-06	1/2	3/8	
	B4006-08-08	1/2	1/2	

#### Return to Index

# B4007 Adaptor, Brass, PTC, D.O.T., 90° Elbow, Swivel



PART NO	TUBE	MPX	
B4007-04-02	1/4	1/8	
B4007-04-04	1/4	1/4	
B4007-04-06	1/4	3/8	
B4007-06-02	3/8	1/8	
B4007-06-04	3/8	1/4	
B4007-06-06	3/8	3/8	
B4007-06-08	3/8	1/2	
B4007-08-04	1/2	1/4	
B4007-08-06	1/2	3/8	
B4007-08-08	1/2	1/2	
B4007-12-08	3/4	1/2	
B4007-12-12	3/4	3/4	

B4008 Ada	0			
	PART NO	TUBE①	MP	TUBE ②
0	B4008-04-02-04	1/4	1/8	1/4
	B4008-04-04-04	1/4	1/4	1/4
	B4008-06-04-06	3/8	1/4	3/8
2	B4008-06-06-06	3/8	3/8	3/8
	B4008-08-06-08	1/2	3/8	1/2

B4009 Adaptor, Brass, PTC, D.O.T., Run Tee, Swivel					
	PART NO	TUBE ①	MPX	TUBE ②	
	B4009-04-02-04	1/4	1/8	1/4	
0	B4009-04-04-04	1/4	1/4	1/4	
	B4009-06-06-06	3/8	3/8	3/8	
	B4009-08-06-08	1/2	3/8	1/2	
	B4009-08-08-08	1/2	1/2	1/2	

B4010 Add	ptor, Brass, PTC	otor, Brass, PTC, D.O.T., Branch Tee				
	PART NO	TUBE ①	TUBE 2	MP		
Contract of the Contract of th	B4010-04-04-02	1/4	1/4	1/8		
0	B4010-04-04-04	1/4	1/4	1/4		
	B4010-06-06-02	3/8	3/8	1/8		
2	B4010-06-06-04	3/8	3/8	1/4		
	B4010-06-06-06	3/8	3/8	3/8		
	B4010-08-08-04	1/2	1/2	1/4		
	B4010-08-08-06	1/2	1/2	3/8		

### Push-to-connect, D.O.T. Air Brake Fittings



#### For D.O.T. Air Brake Tube

#### Adaptor, Brass, PTC, D.O.T., Branch Tee, Swivel **B4011** TUBE 2 MPX PART NO TUBE ① B4011-04-04-02 1/4 1/4 1/8 B4011-04-04-04 1/4 1/4 1/4 B4011-06-06-04 3/8 3/8 1/4 B4011-06-06-06 3/8 3/8 3/8 B4011-08-08-04 1/2 1/2 1/4 B4011-08-08-06 1/2 1/2 3/8 B4011-08-08-08 1/2 1/2 1/2

B4012 Adap	otor, Brass, PT	C, D.O.T., 45° El	bow	
	PART NO	TUBE	MP	
0	B4012-04-02	1/4	1/8	
	B4012-04-04	1/4	1/4	
	B4012-06-02	3/8	1/8	
	B4012-06-04	3/8	1/4	
	B4012-06-06	3/8	3/8	
	B4012-06-08	3/8	1/2	
	B4012-08-04	1/2	1/4	
	B4012-08-06	1/2	3/8	
	B4012-08-08	1/2	1/2	
	B4012-08-06	1/2	3/8	
	B4012-08-08	1/2	1/2	

B4013 Adap	otor, Brass, PTC	C, D.O.T., 45° El	bow, Swivel	1.
	PART NO	TUBE	MPX	
	B4013-04-02	1/4	1/8	
	B4013-04-04	1/4	1/4	
	B4013-06-02	3/8	1/8	
	B4013-06-04	3/8	1/4	
	B4013-06-06	3/8	3/8	
1	B4013-06-08	3/8	1/2	
C SIM &	B4013-08-04	1/2	1/4	
102	B4013-08-06	1/2	3/8	
	B4013-08-08	1/2	1/2	
F. V.	B4013-12-12	3/4	3/4	

#### Brass Compression D.O.T. Air Brake Fittings





### B4201 Adaptor, Brass, Compression, D.O.T., Sleeve



PART NO	TUBE	- 4
B4201-04	1/4	
B4201-06	3/8	
B4201-08	1/2	
B4201-10	5/8	
B4201-12	3/4	

# B4202 Adaptor, Brass, Compression, D.O.T., Nut



PART NO	TUBE	ع الم
B4202-04	1/4	
B4202-06	3/8	
B4202-08	1/2	
B4202-10	5/8	
B4202-12	3/4	

# B4203 Adaptor, Brass, Compression, D.O.T., Straight



PART NO	TUBE	TUBE	
B4203-04-04	1/4	1/4	
B4203-06-06	3/8	3/8	
B4203-08-08	1/2	1/2	
B4203-10-10	5/8	5/8	
B4203-12-12	3/4	3/4	

# B4204 Adaptor, Brass, Compression, D.O.T., Tee



PART NO	TUBE ①	TUBE 2	TUBE③
B4204-04-04-04	1/4	1/4	1/4
B4204-06-06-04	3/8	3/8	1/4
B4204-06-06-06	3/8	3/8	3/8
B4204-06-06-08	3/8	3/8	1/2
B4204-08-08-06	1/2	1/2	3/8
B4204-08-08-08	1/2	1/2	1/2
B4204-10-10-10	5/8	5/8	5/8
B4204-12-12-12	3/4	3/4	3/4

#### Brass Compression D.O.T. Air Brake Fittings

with fixed inserts



# B4205 Adaptor, Brass, Compression DOT, Straight



PART NO	TUBE	MP
B4205-04-02	1/4	1/8
B4205-04-04	1/4	1/4
B4205-04-06	1/4	3/8
B4205-04-08	1/4	1/2
B4205-06-02	3/8	1/8
B4205-06-04	3/8	1/4
B4205-06-06	3/8	3/8
B4205-06-08	3/8	1/2
B4205-08-04	1/2	1/4
B4205-08-06	1/2	3/8
B4205-08-08	1/2	1/2
B4205-08-12	1/2	3/4
B4205-10-06	5/8	3/8
B4205-10-08	5/8	1/2
B4205-10-12	5/8	3/4
B4205-12-08	3/4	1/2
B4205-12-12	3/4	3/4

# B4206 Adaptor, Brass, Compression DOT, 90° Elbow



PART NO	TUBE	MP	
B4206-04-02	1/4	1/8	
B4206-04-04	1/4	1/4	
B4206-04-06	1/4	3/8	
B4206-04-08	1/4	1/2	
B4206-06-02	3/8	1/8	
B4206-06-04	3/8	1/4	
B4206-06-06	3/8	3/8	
B4206-06-08	3/8	1/2	
B4206-08-04	1/2	1/4	
B4206-08-06	1/2	3/8	
B4206-08-08	1/2	1/2	
B4206-10-06	5/8	3/8	
B4206-10-08	5/8	1/2	
B4206-10-12	5/8	3/4	
B4206-12-08	3/4	1/2	
B4206-12-12	3/4	3/4	

#### Brass Compression D.O.T. Air Brake Fittings

with fixed inserts



### B4207 Adaptor, Brass, Compression DOT, Run Tee



PART NO	TUBE ①	MP	TUBE ②
B4207-04-02-02	1/4	1/8	1/8
B4207-04-04-04	1/4	1/4	1/4
B4207-06-04-06	3/8	1/4	3/8
B4207-06-06-06	3/8	3/8	3/8
B4207-08-06-08	1/2	3/8	1/2
B4207-08-08-08	1/2	1/2	1/2
B4207-12-08-12	3/4	1/2	3/4

### B4208 Adaptor, Brass, Compression DOT, Branch Tee



PART NO	TUBE ①	TUBE ②	MP
B4208-04-04-02	1/4	1/4	1/8
B4208-04-04-04	1/4	1/4	1/4
B4208-06-04-04	3/8	1/4	1/4
B4208-06-06-02	3/8	3/8	1/8
B4208-06-06-04	3/8	3/8	1/4
B4208-06-06-06	3/8	3/8	3/8
B4208-08-08-04	1/2	1/2	1/4
B4208-08-08-06	1/2	1/2	3/8
B4208-08-08-08	1/2	1/2	1/2
B4208-10-10-06	5/8	5/8	3/8
B4208-10-10-08	5/8	5/8	1/2
B4208-12-12-12	3/4	3/4	3/4

# B4209 Adaptor, Brass, Compression DOT, 45° Elbow



PART NO	TUBE	MP	
B4209-04-02	1/4	1/8	
B4209-04-04	1/4	1/4	
B4209-06-02	3/8	1/8	
B4209-06-04	3/8	1/4	
B4209-06-06	3/8	3/8	
B4209-06-08	3/8	1/2	
B4209-08-04	1/2	1/4	
B4209-08-06	1/2	3/8	
B4209-08-08	1/2	1/2	
B4209-10-08	5/8	1/2	

#### Brass D.O.T. Air Brake Hose Couplings



#### and Terminal Bolts

## B4601 Adaptor, Brass, DOT Hose Coupling, Sleeve



PART NO	HOSE I.D.	
B4601-06	3/8	
B4601-08	1/2	

# B4602 Adaptor, Brass, DOT Hose Coupling, Nut



PART NO	HOSE I.D.	ب کیے ج
B4602-06	3/8	
B4602-08	1/2	

# B4603 Adaptor, Brass, DOT Hose Coupling, Straight



PART NO	HOSE I.D.	MP
B4603-06-04	3/8	1/4
B4603-06-06	3/8	3/8
B4603-06-08	3/8	1/2
B4603-08-06	1/2	3/8
B4603-08-08	1/2	1/2

# B4605 Adaptor, Brass, DOT Hose Coupling, Straight, Spring



PART NO	HOSE I.D.	MP	
B4605-06-04	3/8	1/4	
B4605-06-06	3/8	3/8	
B4605-06-08	3/8	1/2	
B4605-08-06	1/2	3/8	
B4605-08-08	1/2	1/2	

#### Brass D.O.T. Air Brake Hose Couplings



#### and Terminal Bolts

# B4606 Adaptor, Brass, DOT Hose Coupling, Straight MHAB



PART NO	MHAB	MP	
B4606-06-04	3/8	1/4	
B4606-06-06	3/8	3/8	
B4606-06-08	3/8	1/2	
B4606-08-06	1/2	3/8	
B4606-08-08	1/2	1/2	

# B4607 Adaptor, Brass, DOT Hose Coupling, Straight, FHABX



PART NO	HOSE I.D.	FHABX	
B4607-06-06	3/8	3/8	
B4607-08-08	1/2	1/2	

# B4608 Adaptor, Brass, DOT Hose Coupling, Straight, MPX



PART NO	HOSE I.D.	MP(X)	
B4608-06-04	3/8	1/4	
B4608-06-06	3/8	3/8	
B4608-06-08	3/8	1/2	
B4608-08-06	1/2	3/8	

### **B1112** Adaptor, Brass, NPT, Terminal Bolt



PART NO	FP	FP
B1112-02-02	1/8	1/8
B1112-04-04	1/4	1/4
B1112-06-06	3/8	3/8
B1112-08-08	1/2	1/2



# SAFETY GUIDE



#### **WARNING**

Death, life-changing injury, and destruction of property can result from failure, improper use, or improper selection of hose, tubing, fittings, adaptors, accessories and assemblies.

Possible outcomes include:













- Hose failure and blow out.
- Fluids discharged at high velocity.
- Fittings blown away at high velocity.
- Ignition or explosion of fluid.
- Impact with abruptly descending or moving objects that were held or transported by conveying fluid.
- Dangerously "whipping" hose.

- Electric shock from high-voltage power lines or other electrical sources.
- Flashes or explosions resulting from the accumulation of static electricity.
- Flashes or explosions occurring while applying paint or other flammable liquids.
- Personal contact with conveyed fluids that can be toxic, cold, hot or potentially harmful.

#### A FLUID INJECTION IS A CRITICAL EMERGENCY



### **DANGER - FLUID INJECTION**

Fluid injection injuries can lead to gangrene, loss of limb, or death.

#### **NEVER CHECK FOR LEAKS BY HAND OR GLOVE**

Critical information for Emergency Room doctors:

Type of fluid

- Pressure of injected fluid
- Amount of fluid injected
- Time between injection and treatment

DO NOT LEAVE THE HOSPITAL UNTREATED EVEN IF THERE ARE MINIMAL OUTWARD SIGNS OF INJURY

# FAILURE OR IMPROPER SELECTION OR IMPROPER USE OF THE PRODUCTS DESCRIBED HEREIN, CAN CAUSE DEATH, PERSONAL INJURY AND DESTRUCTION OF PROPERTY.

This document, along with other information provided by GryphonFlex, its affiliated companies, and authorized distributors, offers product or system options for users with technical expertise to investigate further.

The user is entirely responsible for the final selection of the system and its components, ensuring that all performance, endurance, maintenance, safety, and warning requirements for the application are met. The user must thoroughly analyze the application, adhere to relevant industry standards, and consult the product catalog and any additional materials from GryphonFlex or its affiliates or authorized distributors.

If GryphonFlex or its affiliates or authorized distributors offer component or system options based on data or specifications supplied by the user, it is the user's responsibility to ensure that these data and specifications are appropriate and adequate for all intended applications and foreseeable uses of the components.

#### Offer of Sale

The items described in this document are offered for sale by GryphonFlex, its related companies, or its authorized distributors. The terms of this offer and its acceptance are subject to the provisions outlined herein.

#### **Hose Shelf Life**

The shelf life of rubber materials can be influenced by the storage environment. Quantifying shelf life can be challenging due to the numerous variables affecting the hose. By following proper storage precautions, the shelf life can range from three to five years. However, beyond this period, there may be a notable decline in service life, depending on storage conditions.

Factors that can impact this include:

TEMPERATURE: The hose should be kept in a cool, dry location where the temperature does not exceed 100°F (38°C). If stored in freezing conditions, the hose may need to be warmed before handling, testing, or using it.

EXPOSURE: Avoid direct sunlight, rain, heaters, or placement near electrical equipment.

ENVIRONMENTAL FACTORS: Be mindful of humidity and ozone levels.

CHEMICALS: Keep the hose away from oil, solvents, corrosive materials, or fumes.

PESTS: Protect the hose from insects or rodents.

RADIOACTIVITY: Ensure the storage area is free from radioactivity.

SPACE AND HANDLING: Allow adequate space and avoid sharp bends to prevent damage.

Keep the hose in its original container and avoid stacking it too high, as excessive weight can crush the hoses at the bottom of the stack.

We strongly recommend that hoses in extended storage be visually inspected and tested before use. Hoses that appear to be in marginal condition should be replaced to prevent potential failures, property damage, or personal injury. Store hoses using a first-in/first-out approach. Prolonged storage or poor storage conditions can degrade the hose, reduce its performance, and increase the risk of premature failure.

#### Warranty

GryphonFlex hose, fittings and adaptors are warranted to be free from defects in material or workmanship. This warranty is automatically voided where damage occurs due to improper use, abuse, misuse, inadequate maintenance or failure to follow installation, use and service recommendations.

ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY EXPRESSLY DISCLAIMED. IN NO EVENT WILL GRYPHONFLEX BE LIABLE TO ANY PARTY FOR CONSEQUENTIAL, INCIDENTAL, SPECIAL, EXEMPLARY AND INDIRECT DAMAGES, INCLUDING BUT NOT LIMITED TO LOST PROFITS, REGARDLESS OF WHETHER SUCH DAMAGES WERE REASONABLY FORESEEABLE, OR WHETHER GRYPHONFLEX HAD KNOWLEDGE THAT THEY COULD OCCUR.





# Premium-tier performance at standard-tier cost

GryphonFlex is a major new line of hydraulic hose and fittings, pneumatic tube, and other conveyance accessories, that are engineered for use in Canadian mobile and industrial applications.







#### **MILLION CYCLES**

Premium-tier performance that meets or exceeds SAE specifications, including several with million impulse cycle ratings.

### Proven at major OEMs

GryphonFlex has been proven in use by several major OEMs with over half a million feet deployed across a spectrum of demanding applications.



### System-matched assurance

GryphonFlex is a complete system, backed by a staff of hydraulic engineers who can provide SolidWorks hose routing solutions and expert assistance with platform design applications.



gryphonflex.com info@gryphonflex.com

Canada's lowest lifecycle-cost option in hydraulic conveyance.